

CERTISAN C - Hygienising Additive

PRODUCT DESCRIPTION:

Professional laundry hygienising additive compatible with all wash cycles and all fabric types

- Complete hygienising action
- Composition using the latest generation of chemical compounds
- Double active compounds base on oxygen and peracetic acid for a complete action
- Effective on stubborn stains (also on chlorhexidine stains)
- Long lasting hygienising effect
- Developed for both traditional laundries and self-service laundries

DIRECTION FOR USE:

Add Certisan C to the pre-wash and/or the main wash cycle according to the indicated doses. It is recommended to delay the entry of Certisan A (detergent) during the wash cycle to increase the effectiveness of Certisan C. For an extra hygienic and effective result, extend the standard washing cycle by a minimum of 20% or follow the following wash program:

<u>COLOURED GARMENTS</u>	Rotation/pause	Product/water Ratio	Time	Temperature	Product
Pre-wash	20/10 sec.	1:4	12 min.	40° C	CERTISAN A (6 ml/kg) CERTISAN C (6 ml/kg)
Drain + Centrifuge	400 rpm		3 min.		
Main wash	25/5 sec.	1:3	20 min.	40° C	CERTISAN A (12 ml/kg) CERTISAN C (10 ml/kg)
Drain + Centrifuge	600 rpm		3 min.		
Rinse	20/10 sec.	1:4	5 min.	cold	
Drain + Centrifuge	600 rpm		3 min.		
Final rinse	20/10 sec.	1:4	5 min.	cold	CERTISAN B (10 ml/kg)
Drain + Final Centrifuge	1000/1200 rpm		5 min.		

<u>WHITE GARMENTS</u>	Rotation/pause	Product/water Ratio	Time	Temperature	Product
Pre-wash	20/10 sec.	1:4	10 min.	60° C	CERTISAN A (4 ml/kg) CERTISAN C (4 ml/kg)
Drain + Centrifuge	400 rpm		3 min.		
Main wash	25/5 sec.	1:3	15 min.	60° C	CERTISAN A (10 ml/kg) CERTISAN C (8 ml/kg)
Drain + Centrifuge	600 rpm		3 min.		
Rinse	20/10 sec.	1:4	5 min.	cold	
Drain + Centrifuge	600 rpm		3 min.		
Final rinse	20/10 sec.	1:4	5 min.	cold	CERTISAN B (10 ml/kg)
Drain + Final Centrifuge	1000/1200 rpm		5 min.		

Product for professional use only.

The product falls under EU Regulation 2019/1148 of 20th June 2019 concerning the introduction on the market and the use of explosives precursors.



LOGISTIC INFORMATION:

Code	Size	Box	Pallet
A48-200N	20 Kg	-	24

STORAGE: Keep the product in its original packaging at a temperature between 10 and 35 ° C and avoid any leakage of product. Avoid bitter cold and freezing. Do not expose to direct sunlight. It is advisable to preferably use the product within 18 months from production. For further information read the safety data sheet (SDS).

All the instructions provided are the result of studies and experiences acquired and they do not exempt the client from verifying the suitability of the products for the purposes of use. Therefore the application of the products and the results obtained must be considered independent from our responsibility.